

## Ideal Conditions for Forming KYDEX® Sheet

TB - 140-C

### Temperature Profile for Thermoforming KYDEX® Sheet Products

- KYDEX® sheet forms differently than an ABS and Polycarbonate.
- KYDEX® sheet is denser than ABS and Polycarbonate, results in heating the material differently than ABS and PC.
- The recommended temperature profile for heating KYDEX® sheet is, normally achieved by setting the bottom heaters higher than the top heaters.
  - 1) The distance between the bottom heaters and the sheet is greater than the distance between the top heaters and the sheet.
  - 2) Running the bottom heaters higher in temperature allows the heat to rise and be trapped under the sheet, allowing to be absorbed into the KYDEX® sheet faster, reducing the heating time.
  - 3) Running the top heaters lower, reduces the amount of heat being applied to the sheet surface, hence, reducing the gloss level of the part.
- A good starting temperature profile for forming KYDEX® sheet is:
  - 30% top heaters and 70% bottom heaters.
- A good rule of thumb (starting point) on the dwell time (heating) for heating KYDEX® sheet is:
  - For sheet thickness up to 0.125" - 1 second per mil (ex.: 0.125" = 125 seconds)
  - For thicknesses over 0.125" - 1 ¼ seconds per mil (ex.: 0.200" = 250 seconds)
- It is always good to run the perimeter of the ovens 5% to 10% higher than the rest of the settings (depending on ambient temperature).
  - Purpose for doing this, is to help compensate for any air flow across front of the oven.

Example of Top and Bottom Oven Settings for Ceramic, Quartz and Halogen Heaters:

Top Oven							Bottom Oven						
35%			35%				70%			70%			
040%	35%	30%	30%	30%	35%	40%	75%	70%	70%	70%	70%	70%	75%
	30%	30%	30%	30%	30%			70%	70%	70%	70%	70%	
	35%	30%	30%	30%	35%			75%	70%	70%	70%	75%	
40%			40%				75%			75%			
Front							Front						

#### SEKISUI SPI

ISO 9001 and 14001 Certified

#### Customer Service

6685 Low St, Bloomsburg, PA 17815 USA

Phone: 800.325.5133, +1.570.389.5810

Outside the US: +1.570.389.5814

Fax: 800.452.0155, +1.570.387.7786

Email: [info@sekisui-spi.com](mailto:info@sekisui-spi.com)

#### Technical Service

Phone: 800.682.8758

Fax: +1.570.387.8722

Outside the US: +1.570.387.6997

[techservice@sekisui-spi.com](mailto:techservice@sekisui-spi.com)

[sekisui-spi.com](http://sekisui-spi.com)

## Ideal Conditions for Forming KYDEX® Sheet

TB - 140-C

**Thermoforming  
and Mold  
Shrinkage**

**Important  
Thermoforming  
Information**

Example of Top Oven Settings for Gas Catalytic Heaters:

Top Oven						
1.2			1.2			
1.5	1.2	1.0	1.0	1.0	1.2	1.5
	1.0	1.0	1.0	1.0	1.0	
	1.2	1.2	1.2	1.2	1.2	
1.5			1.5			
Front						

Bottom Oven						
2.0			2.0			
2.1	2.0	2.0	2.0	2.0	2.0	2.1
	2.0	2.0	2.0	2.0	2.0	
	2.1	2.0	2.0	2.0	2.1	
2.1			2.1			
Front						

Gas Catalytic Heats operate on CWI (Column of Water Inches)

### Thermoforming Molds:

#### Male Molds

Min. draft angle: 2 - 4°  
 Min. radius: 2.30mm (0.094")  
 Mold shrinkage: 0.40 - 0.60%

#### Female Molds

Min. draft angle: 1 - 2°  
 Min. radius: 1.60mm (0.063")  
 Mold shrinkage: 0.50% - 0.70%

#### Pressure Forming - Female Molds

Min. draft angle 1 - 2°  
 Min. radius 1.6mm (0.063")  
 Mold Shrinkage: 0.40% - 0.50%

### Drying of KYDEX® Sheet:

KYDEX® sheet is less hygroscopic than most thermoplastics and does not require drying. But, if the material has been stored for a period of time in a humid environment, drying may need to be performed.

### Recommended Drying Temperatures and Times:

(at 68°C (155°F) in an air-circulated oven)

#### Sheet Thickness

2.00mm (0.080")  
 3.20mm (0.125")  
 6.40mm (0.250")

#### Minimum Time (hrs)

10  
 16  
 24

#### SEKISUI SPI

ISO 9001 and 14001 Certified

#### Customer Service

6685 Low St, Bloomsburg, PA 17815 USA  
 Phone: 800.325.3133, +1.570.389.5810  
 Outside the US: +1.570.389.5814  
 Fax: 800.452.0155, +1.570.387.7786  
 Email: info@sekisui-spi.com

#### Technical Service

Phone: 800.682.8758  
 Fax: +1.570.387.8722  
 Outside the US: +1.570.387.6997  
 techservice@sekisui-spi.com

[sekisui-spi.com](http://sekisui-spi.com)

## Ideal Conditions for Forming KYDEX® Sheet

TB - 140-C

### Thermoforming Temperature Guidelines

### Forming Technique for KYDEX® Sheet

Forming Surface Temperatures Guidelines:

- Sheet should not exceed 400°F (204°C).
  - 165 - 177°C (330 - 350°F) for 0.71mm - 1.50mm (0.028" to 0.060").
  - 182 - 196°C (360 - 385°F) for 1.50mm - 3.20mm (0.060" to 0.125").
  - 196 - 204°C (385 - 400°F) for 3.20mm and greater (0.125" and greater).
- The recommended temperature ranges are to give you the optima temperature of the KYDEX sheet to achieve good detail and uniform wall thickness.
- To avoid warpage and/or distortion in the formed part, allow the surface temperature of the part to cool below 65.5°C (150°F) before removing the part from the mold.
- If you are using a temperature controlled mold, maintain a mold temperature of 65.5°C (150°F) in the cooling cycle
- Do Not exceed 71.1°C (160°F). This is close to the HDT (Heat Deflection Temperature) of the material.

KYDEX® sheet does not contain any plasticizers, brominated fire retardants, or heavy metal stabilizers, including lead and cadmium.

#### Plasticizers:

Plasticizers are used as softening agents and provide low temperature flexibility and weldability.

#### Flame Retardants:

Brominated Flame Retardants: PentaBDE, OctaBDE, and DecaBDE are brominated flame retardants typically used in thermoplastics such as ABS, Polyethylene, Polyurethane, or Polystyrene to help comply with the stringent UL 94 fire standard. KYDEX® sheet has inherent flame retardant properties so no flame retardant additives are necessary to comply with such a standard.

#### Stabilizers:

Most stabilizers are used in rigid vinyl applications such as construction products thanks to their processability and durability. Lead and cadmium-based stabilizers are used principally in vinyl wire and cable insulation. KYDEX® sheet does not contain any lead or cadmium.

*Note:* Using FR/ABS or ABS temperature profiles, which are more of an even top and bottom temperature profile (50/50, 60/60, etc), KYDEX sheet would very likely be formed with a glossy primary surface, due to the more concentrated heat on top. By using the recommended temperature profile above, the heating cycle times will be comparable to FR/ABS and other thermoplastics.

By having a higher tear strength, KYDEX® sheet will not sag like FR/ABS, ABS and other thermoplastics. So, the use of a sag sensor would need to be adjusted to accommodate the difference in sag rate between KYDEX® sheet and other thermoplastics.

Due to constant changes in forming conditions, relating to ambient temperature changes, drafts on the shop floor, age and condition of the equipment, you can not always rely on fixed cycle times.

Although there are ways of measuring surface temperature to achieve the proper forming temperature (Infrared temperature sensors, paper thermometers, etc.), the most difficult aspect is achieving the proper core temperature as well. By achieving the proper core temperature, internal stresses in the material are reduced, improving part quality and consistency.

#### SEKISUI SPI

ISO 9001 and 14001 Certified

#### Customer Service

6685 Low St, Bloomsburg, PA 17815 USA  
 Phone: 800.325.3133, +1.570.389.5810  
 Outside the US: +1.570.389.5814  
 Fax: 800.452.0155, +1.570.387.7786  
 Email: [info@sekisui-spi.com](mailto:info@sekisui-spi.com)

#### Technical Service

Phone: 800.682.8758  
 Fax: +1.570.387.8722  
 Outside the US: +1.570.387.6997  
[techservice@sekisui-spi.com](mailto:techservice@sekisui-spi.com)

[sekisui-spi.com](http://sekisui-spi.com)

## Ideal Conditions for Forming KYDEX® Sheet

TB - 140-C

**Forming  
Technique for  
KYDEX® Sheet**

**Benefits of Using  
KYDEX® Sheet**

**What to Look  
for During the  
Heating of  
KYDEX® Sheet**

**SEKISUI SPI**  
ISO 9001 and 14001 Certified

**Customer Service**  
6685 Low St, Bloomsburg, PA 17815 USA  
Phone: 800.325.3133, +1.570.389.5810  
Outside the US: +1.570.389.5814  
Fax: 800.452.0155, +1.570.387.7786  
Email: info@sekisui-spi.com

**Technical Service**  
Phone: 800.682.8758  
Fax: +1.570.387.8722  
Outside the US: +1.570.387.6997  
techservice@sekisui-spi.com

[sekisui-spi.com](http://sekisui-spi.com)

Therefore, we suggest that you rely on visual methods as well in determining the correct time to form, rather than relying strictly on cycle time.

The method below relies on sheet appearance. Most likely, your operators are already using this method to some extent. The method is a four-stage sequence that will tell the operator when the sheet is to come out of the oven and will signal when to adjust the oven conditions. By using this four-step method you will achieve higher quality, get greater consistency and have fewer rejects. The bottom line: This method saves you money.

### KYDEX® sheet:

- Is a monolithic sheet (colour throughout), where competitors are mostly capped product
- Exhibits higher impact resistance
- Is easy to thermoform
- Is a great material for pressure forming
- Allows downgrading, reducing cost and weight
- Has excellent extensibility in deep draw thermoformed parts
- Retains its pattern texture after thermoforming
- Provides very good uniform wall thickness in thermoformed parts
- Cycle times are similar in all products
- Produces less rejects in thermoforming due to its quality
- Has short lead times (usually 3 weeks or less)
- Has technical and field support

**Stage 1:** As the material starts to heat, it will begin to soften and bulge up slightly from the heat below it.

**Stage 2:** As the material begins to approach thermoforming temperature, the material will start to form ripples. Ripples are a result of inherent stresses from the extrusion process. They are common in any extruded plastic.

**Stage 3:** As the sheet approaches the thermoforming temperature, the ripples will start to smooth out. If the material is formed at this point, your part would have a lower quality or have higher internal stresses in them than desired. Possibly creating poor part definition and thinning in the side walls. If the surface temperature is already at the proper thermoforming temperature, you may be heating too quickly. You should lower the oven settings and adjust the dwell time.

**Stage 4:** The material is now smooth, free of ripples along the clamping frame and sagging slightly (KYDEX® sheet does not sag as much as ABS). This tells the operator that the core temperature is at the proper temperature. It is now ready to form. The combination of the proper surface temperature and core temperature is the key to achieving better parts, less rejects and cost savings.

Because we cannot anticipate or control the many different conditions under which this information and our products may be used, we do not guarantee the applicability of the accuracy of this information or the suitability of our products in any given situation. Users should conduct their own tests to determine the suitability of each product for their particular purposes. Data in the physical property table represents typical values and are to serve only as a guide for engineering design. Results are obtained from specimens under ideal laboratory conditions. Right to change physical properties as a result of technical progress is reserved. THE PRODUCTS DISCUSSED ARE SOLD WITHOUT WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE, EITHER EXPRESSED OR IMPLIED, EXCEPT AS PROVIDED IN OUR STANDARD TERMS AND CONDITIONS OF SALE. Buyer assumes all responsibility for loss or damage arising from the handling and use of our products, whether done in accordance with directions or not. In no event shall the supplier or the manufacturer be liable for incidental or consequential damages. Also, statements concerning the possible use of our products are not intended as recommendations to use our products in the infringement of any patent. Consult local code and regulatory agencies for specific requirements regarding code compliance, transporting, processing, recycling and disposal of our product. Product not intended for use as a heat resistant surface. Texture, product grade and other conditions may cause variations in appearance.

This information supersedes all previously published data.